

SK-22773-N jun.li

SK-22773-N jun.li

配置二：快装接口(TC)版

袋体体积	管路	取样	货号1(Renolit膜)	货号2(KA膜)
3D 50L	进：100 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $\frac{3}{4}$ "快装接头 (TC25) 出：100 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $\frac{3}{4}$ "快装接头 (TC25)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D50LS21T	K3D50LS21T
3D 100L	进：150 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50) 出：150 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D100S21S	K3D100S21S
3D 200L	进：150 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50) 出：150 cm ID $\frac{3}{8}$ " * OD $\frac{5}{8}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D200S21S	K3D200S21S
3D 250L	进：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50) 出：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D250S21S	K3D250S21S
3D 500L	进：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50) 出：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D500S21S	K3D500S21S
3D 1000L	进：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50) 出：150 cm ID $\frac{1}{2}$ " * OD $\frac{3}{4}$ " Lifemeta® STS铂金硫化硅胶管 + $1\frac{1}{2}$ "快装接头 (TC50)	20 cm ID $\frac{1}{4}$ " * OD $7\frac{1}{16}$ " Lifemeta® STS铂金硫化硅胶管 + 无针取样器	3D100S21S	K3D100S21S